TASKI GS Ecobot Accessory List





ACCESSORIES	Description	SKU	GS Ecobot 50 Pro	GS Ecobot 40
Scrubbing brush for Ecobot 50 Pro	Ecobot Floor brush	7525342	x	
Pad holder for Ecobot 50 Pro	Ecobot Pad holder	7525343	x	
Dust bag for Ecobot 40	Ecobot Dust bag	7525344		x
Brush for Ecobot 40	Ecobot Mini Brush Soft	7525345		x
Brush for Ecobot 40	Ecobot Mini brush Hard	7525346		x
Roller brush for Ecobot 40	Ecobot Roller brush	7525347		x
HEPA filter for Ecobot 40	Ecobot HEPA Filter	7525348		x
Filter for Ecobot 50 Pro	TASKI GS ECOBOT 50P Filter 50micron	7525351	x	
Filter for Ecobot 50 Pro	TASKI GS ECOBOT 50P Filter 100micron	7525352	x	
Filter Bag for Ecobot 50 Pro	TASKI GS ECOBOT 50P Filter Bag	7525353	x	